CEILING FAN REMOTE CONTROLLER
OPERATION AND INSTALLATION INSTRUCTIONS

(Please keep this instruction pamphlet.)

IMPORTANT

YOU MUST SET CEILING FAN MANUAL SWITCH TO HIGH SPEED AND LIGHT KIT (IF ANY) TO BE ON POSITION BEFORE OPERATING REMOTE CONTROL.

IMPORTANT POINTS TO REMEMBER:

1.Read and save these instructions.

2.Please note that all fixed wiring appliances should be installed by a qualified electrician.

3.The supply to the remote control receiver should be connected through a mains switch, i.e. existing wall switch.

4.Disconnect from power supply at wall switch before working on remote control receiver or ceiling fan.

5.Install receiver into the ceiling fan canopy of the fan to ensure proper protection.

6.This unit is to be used for the control of ceiling fan and in a AC110V/120V 60Hz power supply only.

7.Do not install in lamp locations or immerse into water. (For indoor use only.)

8.Do not pull on or cut leads shorter.

9.Do not drop or bump the unit.

10. PLEASE NOTE: The battery will weaken with age and should be replaced before leaking takes place as this will damage the transmitter. Dispose of used battery properly, keep the battery out of reach of children.

11. CAUTION: To reduce the risk of fire or injury, do not use this product in conjunction with any variable (rheostat) wall control.

INSTALLATION INSTRUCTIONS

CAUTION: INCORRECT WIRE CONNECTION WOULD DAMAGE THIS RECEIVER.

1.Ceiling fan must be set at HIGH speed and light kit (If any) at ON position by pulling the “Pull Switch” after installation.

2.Once the connection has been made, the receiver inserts into the drop rod hanging bracket. The canopy comes up to cover the receiver and bracket.



CODE SWITCH

1.CODE SWITCH: Codes are set by pushing dip switches up or down. It is imperative that the code used for both transmitter and receiver is exactly the same; otherwise remote controller will not work. Please note the code switch will enable you to operate a second remote controller independently. For example, if you have two ceiling fans with 2 remote control units, set 2 different codes for each set of transmitter/receivers. This means you can operate each ceiling fan independently.

2.Your remote control is ready for use after battery installation.



FUNCTIONS OF TRANSMITTER

LIGHT：

ON : Press this button and release instantly to turn on fan light.

OFF : Press this button and release instantly to turn off fan light.

FAN：

OFF : Turn off ceiling fan.

HI : Turn on ceiling fan at high speed.

MED : Turn on ceiling fan at medium speed.

LOW : Turn on ceiling fan at low speed.

TRANSMITTER



Ceiling Fan Remote Control Wiring Connection





Installation of Transmitter Wall Mount Holder with two screws.